

Alternative metrology for CMP performances measurement in 3D hybrid bonding

Viorel Balan, Yorrick Exbrayat, Daniel Scevola

▶ To cite this version:

Viorel Balan, Yorrick Exbrayat, Daniel Scevola. Alternative metrology for CMP performances measurement in 3D hybrid bonding. 2021 CAMP CMP Symposium - 24th International Symposium on Chemical-Mechanical Planarization, Aug 2021, Clarkson University (virtual event), United States. cea-03689190

HAL Id: cea-03689190 https://cea.hal.science/cea-03689190

Submitted on 7 Jun2022

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.

leti Ceatech



ALTERNATIVE METROLOGY FOR CMP PERFORMANCES MEASUREMENT IN 3D HYBRID BONDING

CAMP2021 | V. BALAN, Y.EXBRAYAT, D.SCEVOLA





- Paradigm Evolution: from Scaling to Stacking through Hybrid Bonding, a CMP – enabled process
- Data Bridge Market Research analyses that the 3D IC market will exhibit a CAGR of 33% for the forecast period of 2021-2028.



While BEOL CMP is a mature process, CMP for 3D hybrid bonding is much more challenging: Cu pad size is bigger while topography constraints are much more aggressive in order to avoid critical bonding voids





- While BEOL CMP is a mature process, CMP for 3D hybrid bonding is much more challenging: Cu pad size is bigger while topography constraints are much more aggressive in order to avoid critical bonding voids
- Quantifying CMP process performance is done by estimating final topography at different scales, with different metrology techniques





- While BEOL CMP is a mature process, CMP for 3D hybrid bonding is much more challenging: Cu pad size is bigger while topography constraints are much more aggressive in order to avoid critical bonding voids
- Quantifying CMP process performance is done by estimating final topography at different scales, with different metrology techniques
- Correlation between topography amplitude and Scanning Acoustic Microscopy (SAM) images is done in order to improve bonding yield





- While BEOL CMP is a mature process, CMP for 3D hybrid bonding is much more challenging: Cu pad size is bigger while topography constraints are much more aggressive in order to avoid critical bonding voids
- Quantifying CMP process performance is done by estimating final topography at different scales, with different metrology techniques
- Correlation between topography amplitude and Scanning Acoustic Microscopy (SAM) images is done in order to improve bonding yield
- In this work, we developed a image analysis method in order to have a direct quantification of the bonding yield from SAM images and propose best CMP process



What we will talk about

- Improve a CMP process for Hybrid Bonding \rightarrow Quantify Bonding Performance
- CMP Process performances are investigated through High-Resolution Scanning Acoustic Microscopy HR-SAM
 - 3 Cu CMP processes performances were studied : standard, POR process C was compared to new consumables processes C1 & C2
 - 2 Barrier CMP processes performances were investigated: POR process B was compared to process B1
- CMP performances were compared by quantifying bonding yield on 3 different test masks with different design rules:
 - Heterogeneous Mask 1 with pitch and density variations
 - Mask II, with fixed density and pitch variation
 - Mask III, with density variation and fixed pitch
- While we will not give precise process conditions, we will talk about a method to quantify bonding yield



Qualitative Estimation of Bonding Performance



Leti Qualitative Estimation of Bonding Performance

- HR-SAM image of bonded wafers after POR CMP
- Mask I: pitch & density variation



Qualitative Estimation of Bonding Performance

Process signature impact both at

leti

Ceatech

 Wafer level → radial non-uniformity can be seen on the extracted band from the wafer image, indicating CMP process non-uniformity: bonding quality non-uniformity is quantified by white, unbonded zones, giving information on CMP process performance







 Die-Level → we can clearly see that some white squares are repetitive → corresponding Cu arrays with a certain density and/or pitch are not bonded, giving information on mask design performance



Qualitative Estimation of CMP Process Impact on Bonding Quality Cu CMP (1)



- HR-SAM Images obtained for C1 Cu CMP Process show that white pixels ratio is significantly decreased and, also, their radial distribution on the wafer is significantly improved
- Hybrid bonding quality is highly ameliorated by changing from C Cu CMP process to C1 Cu CMP process and CMP process signature is evidenced
- From mask design perspective, at die scale, white pixels ratio seems reduced for C1 Cu CMP process but is difficult to conclude at this stage



Qualitative Estimation of CMP Process Impact on Bonding Quality Cu CMP (2)

Cu C + Barrier B	
PUR	
Cu C1+ Barrier B	
Cu C2 + Barrier B	

Changing for another Cu CMP process conditions, Cu C2, the HR-SAM Image show comparable white pixels ratio and distribution: the hybrid bonding quality seems equivalent
ightarrow choosing the most performant CMP process is difficult in this case



Qualitative Estimation of CMP Process Impact on Bonding Quality **Barrier CMP**

Cu A + Barrier B			=	 			
POR					= = 0 = = = = = 0 = = = = 0 = =		
Cu C1+ Barrier B		= = = = = = = = = = = = = = = = = = = =					
		VV- - 205 205	,				
		- =0= = <u>_</u> 0=	≝ <u>,</u> ≝ , ≣ , ,				
Cu C2 + Barrier B			-				
Cu C2 + Barrier B							
Cu C2 + Barrier B							
Cu C2 + Barrier B Cu C2 + Barrier B1							
Cu C2 + Barrier B Cu C2 + Barrier B1							

Concerning barrier process conditions, comparing B to B1 is difficult, once again: HR-SAM images show comparable white pixels ratio and distribution so choosing the most performant Barrier CMP process in terms for bonding quality is not obvious



Quantification of Bonding Quality



CONFIDENTIAL | DO NOT SHARE WITHOUT LETI/ST AGREEMENT



Bonding Quality Quantification Methodology Unbonded %Area

1/ High Resolution SAM **Image Acquisition**



* Rasband, W.S., ImageJ, U.S. National Institutes of Health, Bethesda, Maryland, USA, https://imagej.nih.gov/ij/, 1997-2018.



3/ FIJI → Surface Analysis Script → Die Extraction → Image Thresholding → White Pixels Extraction → White / Black Pixels Ratio →Unbonded %Area →Mask Design Impact





<u>Wafer Scale</u> Quantification of Bonding Quality **Cu CMP**



While C1 Cu CMP process do show significant reduction of Unbonded %Area, meaning better bonding performance, C2 Cu CMP process lead to slight increase of white, unbonded pixel ratio: bonding performance of C2 process is worse



Wafer Scale Quantification of Bonding Quality Barrier CMP



Band Unbonded %Area



Changing the Barrier CMP Process, from B to B1, helps to reduce Unbonded %Area
HR-SAM Image Analysis -> Detect CMP process performance -> Choose best process for bonding



Die Scale Quantification of Bonding Quality



Similar Unbonded %Area at die scale for the 3 Cu CMP processes

► White pixel distribution highlight repetitive unbonded Cu arrays → Mask design importance in terms of pitch & density



Die Scale Quantification of Bonding Quality



Changing Barrier CMP process from B to B1 show significant white pixels reduction
 Barrier CMP have local impact, at Die scale, allowing to increase bonding process window in terms of density and pitch

Die Scale Quantification of Bonding Quality Unbonded Cu Arrays Identification



Based on mask design file (left-side), unbonded Cu arrays were identified and counted on HR-SAM Image (middle)

- Graph on right-side shows that, for these specific conditions, a large number of Cu-arrays (white bar on graph) were not bonded:
 - ~ 56% unbonded arrays (white bar)
 - ~38 bonded arrays (black bar)

leti

Ceatech

▶ ~6% mixed (grey bar) : these arrays, on limit between bonded/unbonded are important to focus on for CMP process optimization



Die Scale Quantification of Bonding Quality **Density Influence**



- Low Cu density patterns allow high bonding yield
- Increasing Cu density decrease bonding yield
- There is a Cu density threshold, above which spontaneous hybrid bonding do not occur



Die Scale Quantification of Bonding Quality Line Width Influence



- Thinner Cu lines show better bonding yield across the different Cu arrays densities
- ► In design terms, for Cu density & pitch, Smaller is Better for bonding performance



Validation of the Quantification Protocol



CONFIDENTIAL | DO NOT SHARE WITHOUT LETI/ST AGREEMENT

LetiWafer ScaleQuantification of Bonding QualityCMP Process Impact

HR-SAM Image analysis was validated on different masks (II & III)



- While for heterogeneous Mask I, CMP Process Conditions Impacted Unbonded %Area, for Mask II (pitch variation) and Mask III (density variation) changing CMP process conditions doesn't seem to have significant impact, as wafers are completely bonded
- More homogenous designs as masks Mask II and Mask III are very robust against CMP process conditions

Band Unbonded %Area





<u>Die Scale</u> Quantification of Bonding Quality **Design Impact**



- For all masks, bonding yield performance is independent of Cu CMP Process performance (for investigated conditions...)
- Mask I, bonding performance at Die Scale is impacted by Barrier CMP Process
- Mask II, with pitch variation show excellent bonding quality for B & B1 barrier CMP processes
- Mask III, with density variation, show best bonding yield, with no unbonded/white pixel, independently of investigated Cu or Barrier CMP process



B

Ш

В

C1

B1

C2

В

C1

B

C2

Die Unbonded %Area

14

12 -

10

8

6

4

2 -

0

В

С

В

C1

B

B1

C2

Unbonded%Area

Barrier CMP

Cu CMP

MASK



- Alternative metrology, based on HR-SAM image analysis, was used in order to quantify bonding quality.
- Method including image thresholding, white/black pixel ratio extraction with automated FIJI scripts was used
- Hybrid bonding quality was quantified : different CMP processes and design masks
 - Wafer scale \rightarrow CMP process signature,
 - ▶ Die scale \rightarrow impact of pattern design
- ► Heterogeneous Mask I (density & pitch) → Impact of Cu CMP process: changing Cu CMP Process from POR C to new processes C1 & C2 show significant improvement
- Homogenous Mask II (pitch variation) and Mask III (density variation) : much more robust in terms or Cu CMP process window
- ► For the Barrier CMP, bonding yield is sensitive at die scale → the pattern design is very important, homogenous masks II & III showing very low or even no unbonded area.
- Smaller is better for both pitch and density in terms of bonding performance
- Proper CMP process tuning is important and has to be developed/optimized for different masks layouts
- Image Analysis through Machine Learning available directly on Scanning Acoustic Microscopes would help to improve hybrid bonding process development

This work was funded thanks to the French national program "Programme d'Investissement d'Avenir IRT Nanoelec" ANR-10-AIRT-05 and to ENIAC Joint undertaking "Pilot Optical Line for Imaging and Sensing" (POLIS) project.

The authors would like to thank Frank Fournel, Gaelle Mauguen, Lucile Arnaud, Emilie Bourjot, Nicolas Bresson for their contributions and helpful remarks



CEA-Leti, technology research institute Commissariat à l'énergie atomique et aux énergies alternatives Minatec Campus | 17 avenue des Martyrs | 38054 Grenoble Cedex | France www.leti-cea.com



CAMP2021 | V. BALAN, Y.EXBRAYAT, D.SCEVOLA