

Optical fibre distributed strain measurement for H_2 COPV damage assessment

Laurent Maurin, Pierre Ferdinand, Fabien Nony, Stéphane Villalonga

▶ To cite this version:

Laurent Maurin, Pierre Ferdinand, Fabien Nony, Stéphane Villalonga. Optical fibre distributed strain measurement for H_2 COPV damage assessment. PHASE 2018 convention: Pressurized Hydrogen and Storage Equipment, May 2018, Tours, France. cea-04001477

HAL Id: cea-04001477 https://cea.hal.science/cea-04001477

Submitted on 22 Feb 2023

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers.


L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.




OPTICAL FIBRE DISTRIBUTED STRAIN MEASUREMENTS FOR H₂ COPV DAMAGE ASSESSMENT

PHASE 2018 Convention - Tours - the 15th of May, 2018 | L. Maurin

CEA LIST | Laurent Maurin – Pierre Ferdinand
CEA DAM | Fabien Nony – Stéphane Villalonga







the 15th of May: 15h45 - 16h15













list





TABLE OF CONTENTS

- A brief overview of H2E research program
- Technological background, advantages of distributed measurements for COPV
- Optical fibre in COPV: is it safe or not?
 - Some experimental results Towards a first criterion
- In situ OFDR Rayleigh measurements
- Differential strain profiles analysis principle
- · Low pressure, and residual differential strain analysis
- · Additional SHM criteria: differential strain sensitivity and damage assessment
- One page key results





H2E RESEARCH PROGRAM

- A response to an energy challenge
 - Durable mobility
 - Greenhouse gas reduction
 - · Petroleum dependence reduction



- Hydrogen is a short term answer to these challenges
- Main markets
 - Uninterruptible power supply in isolated areas
 - Emergency power supply (telecom, hospitals, data centres...)
 - · On-board **vehicle** electrical energy production for a clean and silent propulsion
- Technologies: fuel cell, high pressure storage vessels, ...
- Technological research program co-funded by **OSEO** for 67,6 M€, for a global investment close to 200 M€ during 7 years (started on the 8th of October, 2008)
- This research program ended in 2015

website: http://www.planete-hydrogene.com/





TYPE IV HIGH PRESSURE STORAGE VESSELS

transportable:

 type IV pressure vessel: composite materials structure with polymer liner



H2E research program:

type IV Composite Overwrapped

Pressure Vessels (COPV)

700 bar (security factor: 2.25)

525 bar (security factor: 3)

fireman's vessel



• regulation: directive 97/23/EC of the European Parliament and the Council of 29 May 1997 and the approximation of the laws of the Member States concerning pressure **equipment.** OJ L 181 (1997)

- project goal: to set-up a new inspection method capable to:
- Determine whether the vessel is safe or not

source: EADS Composites Aquitaine™ Raise vessel lifetime thanks to a better Structural Health Monitoring

STANDARDS

• **ISO 11623**: "Transportable gas cylinders – Periodic inspection and testing of composite gas cylinders"





OPTICAL FIBRE SENSORS FOR SHM OF COMPOSITE VESSELS (1/3)





Figure 1. Strain imaging system scans fiber sensor arrays to locate damage

sources: Blue Road Research™ (Eric Udd)







- · What about the detection of internal defects?
- High speed, but expensive (several FBGs)
- Complicated for high volume storage vessels





Figure 7. Ultrasonic (bottom) scans compare impact damage with strain imaging (top)

acoustic emission




Eddy current







OPTICAL FIBRE SENSORS FOR SHM OF COMPOSITE VESSELS (2/3)

- ZEM project (FP5) : **SOFO** SMARTape[™] (Smartec[™] Branko Glisic)
 - · Flaw detection with strain sensitivity variation vs. pressure





sources: Smartec™, ZEM project





- Global inspection method via a global sensitivity parameter
- Sensor intrusivity questionable in case of *in situ* measurements





OPTICAL FIBRE SENSORS FOR SHM OF COMPOSITE VESSELS (3/3)

Optical fibre sensors for pressure vessel inspection is not new ...


Philips (1982)








Morgan Research Corp. (2005)




Boeing (2004)



Lockheed Martin (2005)

(54) Fiber optic impact sensing system and method of using same







DISTRIBUTED MEASUREMENT TECHNIQUE AND INTERESTS

- Based on OFDR Rayleigh with optical fibre(s) embedded into the composite structure during the manufacturing process
- A distributed measurement / precision & accuracy: a few µm/m
 - · Same sensors during the vessel lifetime
 - In the same carbon reinforcement fibres orientation
 - · Close to internal defects (if any ...)
 - Thermo-mechanical information (in our case, only mechanical since the temperature is controlled)
- Internal defects are precisely **located** along the optical fibre (typ.: 2 cm sampling)

OPEN QUESTIONS

- Intrusive effect of the optical fibre on the mechanical performances (Pressure Equipment directive and ISO standards)
 - Tests on flat samples → up to their ultimate tensile strength
 - Tests on NOL rings → fatigue tests
- Structural defects highlighting?
 - · A proposal for 4 new SHM criteria, including a Damage Assessment Parameter






FLAT SAMPLES MANUFACTURING

- 5 series within a same mould
 - 24 sets x 5 samples → 120 samples manufactured and tested
 - · 10 plies/sample
 - Plies orientations: 0°, 10°, 30°, 45°, 70°, 85°, 90°



1. pre-preg carbon-expoxy with optical fibres laid on surface



optical fibres are aligned in the direction of the reinforcement carbon fibres

optical fibres embedded quantity >>> planned in pressure vessels


expected impact on mechanical performances is maximised



2. flat samples cut at required dimensions



3. plies stacked one on another




4. vacuum moulding





ULTIMATE TENSILE STRENGTH PERFORMANCE ANALYSIS

- 3 kinds optical fibres tested (A, B and C)
- Uniaxial tensile tests (250 kN testing machine)
 - Tests up to the samples ultimate tensile strength
- In situ FBG strain measurements
- Strain and stress statistical analysis → no significant influence on the ultimate tensile strength
 - · Therefore, expected impact on pressure vessels should not be significant





250 kN tensile test machine

flat sample after test









IN SITU FBG STRAIN MEASUREMENTS vs. TENSILE FORCE

- In situ measurements depend on carbon fibre orientation vs. tensile force direction
- Matrix debonding appears sooner when the angle between the tensile force and the reinforcement carbon fibres is greater
- Debonding can be interpreted as a structural defect outlined by the strain (FBG) measurement

As soon as debonding appears, FBG strain measurement deviates from sample average strain FIRST BASIS FOR A STRUCTURAL DEFECT DETECTION CRITERION









NOL RING FATIGUE TESTS (1/4)

- ASTM D2290-08 standards: "Standard Test Method for Apparent Hoop Tensile Strength of Plastic or Reinforced Plastic Pipe by Split Disk Method"
 - NOL ring geometry more representative of cylindrical shells
 - · The optical fibre also acts as a reinforcement fibre
- 4 different NOL rings series were machined in the same cylinders
 - · 30 NOL rings tested with different plies orientations
- Fatigue cycles monitored in displacements
 - 15000 cycles according to EIHP standards (-10% +70% amplitude to ultimate tensile strength)



NOL rings



NOL ring installed on the testing machine




NOL ring after fatigue cycles



NOL RING FATIGUE TESTS (2/4)


- $\Delta F = 30 \ kN$ and $\Delta h < 2 \ mm$
 - Frequency: 0.4 Hz (40000 cycles ↔ 28 hours)
 - · Displacement accuracy: better than 1 μm
- Force and displacements continuously recorded
 - Access to strain cycle energy E_{cycle}


$$E_{cycle} = \left| E_{half-cycle} \right| + \left| E_{half-cycle} \right|$$



typical fatigue cycle force & displacement almost superimposed

- The energy parameter is the most relevant, especially during the first cycles
 - \cdot Strain energy E_{cycle} always decreases, whereas the force amplitude may increase
 - Energy parameter better describes the sample average resistance $\langle F \rangle$ to strain





$$\langle F \rangle = \frac{E_{cycle}}{2 \Delta h}$$

 $\langle F \rangle$: average force



NOL RING FATIGUE TESTS (3/4)

- Moreover, analysis of the energy parameter, based on first cycles dispersion, demonstrates that number of cycles to failure $N_{failure}$ is not relevant
 - Energy dispersion <u>during the first fatigue cycles</u> is the main reason for the dispersion of the numbers of cycles to failure


	S [J/Mcycle]	⟨ <i>E</i> ⟩ [J]	Δ <i>E</i> _{N=0} [J]	∆ h [mm]	position reproducibility $\delta N_{\delta h}$ [cycle/ μ m]	first cycles strain energy dispersion $\delta N_{\Delta E_{N=0}}$ [cycle/J]
#1 w/	484,64	45	20,9	1,92	48,36	2063
#1 w/o	378,58	40	9,5	1,92	55,03	2641
#2 w/	77,71	34	9,9	1,65	265,16	12868
#2 w/o	121,2	34	6,6	1,65	170,02	8251

- Number of cycles to failure due to:
 - sample position reproducibility $\delta N_{\delta h}$

$$\delta N_{\delta h} = \frac{1}{S} \frac{\langle E \rangle}{\Delta h} \delta h$$

· first cycles energy dispersion $\delta N_{\Delta E_{N=0}}$

$$\delta N_{\Delta E_{N=0}} = \frac{\Delta E_{N=0}}{S}$$



batch #1 w/o optical fibre batch #1 w/optical fibre batch #2 w/o optical fibre batch #2 w/optical fibre

Not possible to conclude about any significant impact of embedded optical fibres on mechanical performances


First cycles strain energy has first to be better controlled







NOL RING FATIGUE TESTS (4/4)

- Microscope post mortem analyses:
 - No debonding in the optical fibre vicinity
 - Optical fibre perfect integration into the carbon composite structure



no structural defect in the optical fibre vicinity





Not enough reasons to conclude about any significant impact of optical fibres on the samples mechanical performances [compliant with previous results: Sansonetti et al. 1991]




IN SITU PRESSURE VESSELS MEASUREMENTS

- Experimental set-up
 - Semi-automated measurement loop (Luna™OBR-4600 instrument remotely controlled)
 - · 46 pressure steps up to burst pressure
- Small pressure steps enable more complete analyses
- Strain profile analysis $\Delta \varepsilon_{P_0 \to P_n}(s) = \sum_{i=1}^{n} \Delta \varepsilon_{P_{i-1} \to P_i}(s)$



surface impact







Composites Aquitaine™ burst test facility



DIFFERENTIAL STRAIN PROFILE PRINCIPLE

Defect detection criterion relies on flat samples FBG observations

One hypothesis amongst others is to consider internal defects as structural weaknesses resulting, in their vicinity, in local strains different from the rest of the structure supposed undamaged.

With a set of appropriate differences between strain profiles, it must be possible to reveal these defects.

A proposal is to compute a "differential strain profile" between 2 pressure states at P_{ref} and P

$$\delta_{K} \Delta \varepsilon_{(P_{0}, P_{ref}, P)}(s) = \Delta \varepsilon_{P_{0} \to P}(s) - K_{(P_{0}, P_{ref}, P)} \times \Delta \varepsilon_{P_{0} \to P_{ref}}(s)$$

 $K_{(P_0,P_{ref},P)}$ calculated by least-squares minimisation of $\|\delta_K\Deltaarepsilon\|$

- $\rightarrow \delta_K \Delta \varepsilon$ is always centered on zero
- → any significant deviation from zero points out local abnormal strains → defect occurrence probability



DIFFERENTIAL STRAIN ANALYSES TO HIGHLIGHT INTERNAL DEFECTS

 Pressure vessels with embedded optical fibres, manufactured by Composites Aquitaine™





Composites Aquitaine™ pressure vessels



surface defect

- Water-filling procedure / no temperature crosstalk effect
- High signal / noise ratio










LOW PRESSURE AND RESIDUAL STRAINS DIFFERENTIAL ANALYSIS

- High signal / noise ratio enables low pressure analyses
 - → No additional damage due to the inspection method
 - → Residual differential strain profile gives relevant and complementary information



"IOW pressure" (40 bar) differential strain profile

residual differential strain profile



ADDITIONAL SHM CRITERIA

- Strains profiles $\Delta \varepsilon_{P_0 \to P_n}$
 - Highlights pressure vessel mechanical behaviour vs. inflating pressure

$$\Delta \varepsilon_{P_0 \to P_n}(s) = \sum_{i=1}^{i=n} \Delta \varepsilon_{P_{i-1} \to P_i}(s)$$

- Differential strain profiles $\delta_K \Delta \varepsilon$
 - Early defect detection and localisation along the optical fibre

$$\delta_{K} \Delta \varepsilon_{(P_{0}, P_{ref}, P)}(s) = \Delta \varepsilon_{P_{0} \to P}(s) - K_{(P_{0}, P_{ref}, P)} \times \Delta \varepsilon_{P_{0} \to P_{ref}}(s)$$

- Differential strain profile sensitivity $\mathcal{S}_{(P_0,P_{ref},P)}$ vs. inflating pressure P
 - Highlights structural damage acceleration (requires simultaneous pressure measurement)

$$S_{(P_0,P_{ref},P)}(s) = \frac{\partial \delta_K \Delta \varepsilon_{(P_0,P_{ref},P)}(s)}{\partial P}$$

- Damage Assessment Parameter $\mathcal{D}_{(P_0,P_{ref})}$
 - Global damage parameter


$$\mathcal{D}_{\left(P_{0},P_{ref}\right)}(P) = \frac{P\left(K_{0\left(P_{0},P_{ref},P\right)}\right) - P\left(K_{\left(P_{0},P_{ref},P\right)}\right)}{P_{burst}}$$





DIFFERENTIAL STRAIN PROFILE SENSITIVITY ${\cal S}$


• Highlights instantaneous structural damage during filling pressure





DAMAGE ASSESSMENT PARAMETER ${\mathcal D}$

- Highlights structural damage
- Global and robust parameter: relevant even in case of optical fibre break





PRESSURE VESSEL DAMAGE ASSESSMENT



EMBEDDED SHM SOLUTION THROUGHOUT VESSEL LIFETIME

- Distributed measurements based on optical fibre in situ strain measurements
- Global structural damage assessment based on differential analysis
- No additional damage due to the inspection method
 - Validated in isothermal conditions on 700 bar H₂ pressure vessels
 - Early damage detection starting from 40 bar
- ATEX compatible measurement



https://hal.inria.fr/hal-01021252/PDF/0192.pd





Composites Aquitaine™ pressure vessels

pressure vessel strain profiles during burst test

curvilinear position [a.u.]

0.9

0.8


0.7

0.6


0.5

0.4

0.2 0.1



lifferential strain [a.u.]



curvilinear position [a.u.]


strain profiles











strain sensitivity coefficient $K_{(P_0,P_{mf},P)}$ [a.u.]

filling pressure P [%



thank you for your attention



Commissariat à l'énergie atomique et aux énergies alternatives Centre de Saclay | F-91191 Gif-sur-Yvette Cedex T. +33 (0)1 69 08 44 24 | F. +33 (0)1 69 08 60 30

Etablissement public à caractère industriel et commercial | RCS Paris B 775 685 019

Direction de la Recherche Technologique
Laboratoire d'Intégration des Systèmes et des Technologies
Département Métrologie, Instrumentation et Information
Laboratoire Capteurs et Architectures Électroniques