

Ceatech







Primary reference in terms of air kerma for ionizing radiation fields produced by a electrostatic accelerator

LABORATOIRE NATIONAL HENRI BECQUEREL CEA-LNE-LNHB

J.M. Bordy, V. Blidéanu, A. Chapon*, F. Delaunay, G. Dupont*, D. Dusciac, J. Gouriou, F. Laine, M. Le Roy

* ATRON METROLOGY

Congrès International de Métrologie | 25 Sept. 2019





French regulation:

Mandatory renewing of radiative source every 10 years Extension of use for 5 years after integrity check

Additional operating costs for French calibration laboratories

Take advantage of this difficulty

Previously:

Reference high energy radiation fields for radiation protection (Medical LINAC Saturne 43)

- Electrons energy 18 MeV
- ▶ target + filter -> Bremssthalung X-rays $\overline{E} \sim 7 \text{ MeV}$

Needs expressed by a private company « ATRON METROLOGY » to establish a new calibration / verification service for dosimeters based on a LINAC beam for a lower <u>energy domain namely close to ¹³⁷Cs (0.662 MeV)</u>





Establish the metrologycal traceability

of the ATRON METROLOGY radiation fields to the SI

1) ATRON METROLOGY facility

*2*2tech

- 2) Determination of the fluence distribution
- 3) Calculation of the conversion coefficient from air kerma toward ambient dose equivalent (quantity used for area dosimetry)
- 4) Traceability to the CEA-LNE-LNHB national references
- 5) Design of a primary vented cavity chamber
- 6) Results of primary measurement on site of the air kerma normalized to the monitors



Description of the ATRON METROLOGY facility

Electrostatic accelerator - Singletron HVEE (High Voltage Engineering Europa B.V.)



Laboratoire National Laboratoire National Henri Becquerel

Ceatech

Congrès International de Métrologie 2019 | Bordy Jean-Marc | 4

We need to know the fluence distribution without the spectrometer perturbation to:

- □ Calculate the correction factors to be applied to the primary measurement of air kerma with an ionization chamber
- \Box Calculate the conversion coefficient from air kerma into ambient dose equivalent (Sv / Gy)

<u>First of all</u> : Calculate the "spectra" at the measurement point in air (MCNP)





Ceatech **Spectrometry (validation of calculations)**

MCNP

Comparison of calculation and measurement of the raw spectra



Above the threshold, very good agreement between the calculated and measured spectra

The comparison of the pulse distributions validates the use of the code therefore the calculation of the spectra



U.A.

0 0E+00 Congrès Interna

4 SE-01



with

Ceatech Conversion to dose equivalent / Traceability to SI





Ceatech Air kerma primary measurement

11/1



 $\prod_i k_i$: Correction factors for the perturbation due to the IC itself (electron and photon fluence, attenuation diffusion in the IC wall, radiative air kerma)

$$I_{cor/monit} = \frac{(I_{raw,CI} - I_{BG,CI}) \prod_{j} k_{j}}{(I_{raw,monitor} - I_{BG,monitor})} \qquad A / M.U.$$

 $I_{raw,XX}$: Average value of the current at the measurement point under irradiation. (A C) $I_{BG,XX}$: Average value of the current at the measurement point with the beam off. (M.U.) $\prod_{j} k_{j}$: Correction factors (humidity, diffusion of the RX on the IC stick, influence of the temperature on the capacitor value).



Ceatech CEA-LNE-LNHB Primary dosemeter design





Very close to unity so very good collection efficiency



Congrès International de Métrologie 2019 | Bordy Jean-Marc 9

Ceatech CEA-LNE-LNHB Primary dosemeter design



Congrès International de Métrologie 2019 | Bordy Jean-Marc | 10

Results, 3 MV at 1 m

Parameter	Value	Standard uncertainty
(I _{cor} -BF)/(Monit-BF)	-1,0475E-04	0,405%
Volume	7,1735	0,004%
Air density (g/cm ³)	1,2047E-03	0,001%
k _{pol}	1,0017	0,286%
ks	0,9994	0,573%
k _{stick}	0,9983	0,257%
A _{wall}	0,9798	0,200%
(μ _{en} / ρ)air,graph	0,9975	1,000%
(S/ρ) graph,air	0,9979	1,000%
W _{air} /e (J/C)	33,97	0,350%
1-gair	0,9968	1,400%
Ka / monit (Gy/M.U.)	2,52E+04	2,183%
h*(10)	1,20	0,200%
H*(10) / monit (Sv/M.U.)	3,02E+04	2,2%

Confirmation that k_{pol} k_s are very close to unity

Uncertainty mainly due to µ, S and g

Uncertainty is better than it would have been using a transfer device





An innovative way to meet the needs of nuclear industry in terms of dosemeter verification and calibration services has been developed through an efficient collaboration between the French national metrology lab (CEA-LNE-LNHB) and industry

CEA- LNE-LNHB maintains and develops its irradiation and calibration capabilities thanks to the French legislation



"The best things one can do are the things we do together"

Thank you for your attention

 $\dot{K_a} = \frac{I_{cor/monit}}{V \rho_{air}} (W/e)_{air} \prod_i k_i$





ceatech



Congrès International de Métrologie 2019

Primary reference in terms of air kerma for ionizing radiation fields produced by a LINAC